

Red line (Positive triggered systems or ground triggered systems) (control the dome light)

SL10.4Fi

10.4" (264mm) FLIP-DOWN TFT MONITOR
 WITH BUILT-IN INFRARED TRANSMITTER

12.2010

User's Manual



SOUNDSTORM[®]
 LABORATORIES

3451 LUNAR COURT, OXNARD CA 93030
 PHONE: 888.38.STORM
 805.983.8008
 FAX: 805.983.7068

TECHNICAL SUPPORT
www.soundstormlab.com



iPod® is a trademark of Apple, Inc.
 registered in the U.S. and other countries.

Sound Storm Laboratories is not affiliated with Apple, Inc.



SL10.4Fi


10.4" (264mm) FLIP-DOWN TFT MONITOR
 WITH BUILT-IN INFRARED TRANSMITTER



- | | |
|-----------|-------------------|
| 1.IR | 5.Adjust- |
| 2.Power | 6.AV1 |
| 3.Menu | 7.V2 |
| 4.Adjust+ | 8.Remote Receiver |

Remote control

- 1.Power On/Off
- 2.AVselect
- 3.Negative adjustment
- 4.mode
- 5.Positive adjustment
- 6.MENU



Specifications

System:	PAL/NTSC
Power source/Consumption:	DC 12V+/-10%,>700mA
Video Input:	Composition Video signal
Operating Temperature:	0°C~+40°C
Storage Temperature:	-10°C~+60°C
Display Method:	Color LCD
Resolution(HXV):	1152X234pixels

Polarity Switch on the back :

For negative dome light trigger systems place rear switch to the "-" position and for vehicles with positive dome light trigger place switch to the "+" position

Cautions

- Do not use in vehicles with 24 volts systems
- Do not expose the monitor to high humidity. Dust, Steam, oily smoke, direct sunlight etc.
- For your safety, please turn power off when not in use and unplug the adaptor.
- Never attempt your own maintenance. Consult your dealer or the company.
- Avoid dropping and strong impact.
- For your safety, the driver should not watch the TV while driving.

Accessories

1xRemote control
1xUser's manual

Mounting Screw

WARNING:
DO NOT WATCH MONITOR WHILE VEHICLE IS IN MOTION. IT IS HAZARDOUS TO YOU AND OTHERS